





LOADER HYDRAULICS (BEFORE LOADER S/N 4110090)

REF.	PART NO.	DESCRIPTION	REQ'D
40	221- 411	ELBOW - 90° street (1/8" NPT)	1
41	D 29650	GAUGE - hyd. oil pressure	1
42	D 30524	HOSE - to filter (1" I.D. x 1-1/2" O.D. x 9" long)	1
43	214- 256	CLAMP - D30524 hose	2
44	221- 211	NIPPLE - 3/4" NPT x 1-3/8" long (If used)	1
45	221- 65	BUSHING - reducing, 1" NPT to 3/4" NPT (Used with D32254 filter) If required	2
46	217- 156	CONNECTOR - filter inlet, str. (1" NPT x 1" O.D. tube) If used	1
47	D 31338	FILTER - hyd. oil, early production (Parts list page 21) Use D32254	1
48	D 32254	FILTER - hyd. oil, late production (Parts list p. 71)	1
49	13- 816	HHCS - 1/2" - 13 NC x 1"	1
50	92- 8	WASHER - med. sect. lock (1/2")	2
51	195- 33	WASHER - plain (1/2")	2
52	221- 415	ELBOW - street, 90° (3/4" NPT) If used	1
53	221- 215	NIPPLE - 3/4" NPT - 2" long (If used)	1
54	221- 405	ELBOW - street, 45° (3/4" NPT) If used	1
55	217- 136	ELBOW - filter outlet, 90° (1" NPT x 1" O.D. tube) If used	1
56	D 30525	HOSE - return (1" I.D. x 1-1/2" O.D. x 28-1/2" long) Used with 221-215 nipples	1
57	D 32678	HOSE - return (1" I.D. x 1-1/2" O.D. x 29" long) Used with 217-136 and D33590 elbows	1
58	214- 256	CLAMP - return hose	2
59	D 28486	ELBOW - 90° street (3/4" NPT) If used	1
60	D 33590	ELBOW - 90°, 3/4" NPT x 1" O.D. tube (If used)	1
61	221- 14	PLUG - 1/2" NPT	1
62	D 23143	ELBOW - male, 90° (Long) Rear valve port to lift cyl. tube (5/8" JIC x 5/8" JIC)	1
63	218- 5007	SEAL - "O" ring, D23143 elbow	1
64	218- 5107	ELBOW - male, 90° (Short) Front valve port to lift cyl. tube (5/8" JIC x 5/8" JIC)	1
65	218- 5007	SEAL - "O" ring, 218-5007 elbow	1
66	D 31357	TUBE - from rear port	1
67	D 31350	TUBE - from front port	1
68	218- 595	TEE - male (5/8" JIC)	2
69	D 31352	TUBE - to R.H. lift cyl. (Long)	1
70	D 31356	TUBE - to R.H. lift cyl. (Short)	1
71	D 30531	TUBE - cross-over (Front)	1
72	D 30565	TUBE - cross-over (Rear)	1
73	D 30533	HOSE - to rear cylinder ports (1/2" I.D. x 1" O.D. x 26" long)	2
74	218- 5007	SEAL - "O" ring, D30533 hose	1
75	D 30541	HOSE - to front cyl. ports (1/2" I.D. x 1" O.D. x 27-1/2" long)	2
76	70724	CLAMP - plate (If used)	4
77	13- 532	HHCS - 5/16" - 18 NC x 2" (If used)	2
78	92- 5	WASHER - med. sect. lock (If used)	2
79	25- 105	NUT - hex. (5/16" - 18 NC) If used	2
80	214- 264	CLAMP - tube (If used)	2
81	D 31460	TUBE - R.H. lift cyl.	1
82	D 31459	TUBE - L.H. lift cyl.	1
83	218- 5062	CONNECTOR - 5/8" JIC x 5/8" JIC	2





(Con't on next page)



LOADER HYDRAULICS (BEFORE LOADER S/N 4110090)


REF.	PART NO.	DESCRIPTION	REQ'D
84	218- 5007	SEAL - "O" ring, 218-5062 connector	1
85	D 31463	CYLINDER - lift, R.H. (Parts list p. 67)	1
86	D 31464	CYLINDER - lift, L.H. (Parts list p. 67)	1
87	D 25137	TEE - adj. (5/8" JIC) Rear valve port to bucket cyl. hose	1
88	218- 5007	SEAL - "O" ring, D25137 tee	1
89	50003	ELBOW - 90° swivel, 5/8" JIC	1
90	D 26168	TEE - adj. (5/8" JIC) Front valve port to bucket cyl. hose	1
91	218- 5007	SEAL - "O" ring, D26168 tee	1
92	D 30537	HOSE - to rear port hydra-leveling cyl. (1/2" I.D. x 1" O.D. x 19-3/8" long)	1
93	218- 5007	SEAL - "O" ring, D30537 hose	1
94	D 30539	HOSE - to front port hydra-leveling cyl. (1/2" I.D. x 1" O.D. x 23-1/8" long)	1
95	218- 5007	SEAL - "O" ring, D30539 hose	1
96	D 31225	CYLINDER - hydra-leveling (Parts list p. 71)	1
97	D 30543	HOSE - to bucket cyl. tubes (3/8" I.D. x 1" O.D. x 29" long)	1
98	R 15257	CLAMP - plate, plastic coated (if used) See items 102-106	2
99	D 20302	CLAMP - hose, plastic coated (if used) See items 102-106	2
100	13- 524	HHCS - 5/16" - 18 NC x 1-1/2"	2
101	92- 5	WASHER - med. sect. lock (5/16")	1
102	25- 105	NUT - hex. (5/16" - 18 NC)	1
103	D 33316	CLAMP - plate, plastic coated	2
104	13- 532	HHCS - 5/16" - 18 NC x 2"	1
105	D 33554	SPACER - clamp plates	3
106	95- 5	WASHER - std. wrot (3/8" I.D. x 7/8" O.D. x 5/64" thick)	1
107	131- 4	NUT - hex., lock (5/16" - 18 NC)	1
108	D 31361	TUBE - on lift arm, outside	1
109	D 31359	TUBE - on lift arm, inside	1
110	38331	CLAMP - tube, metal (Use R17319)	7
111	R 17319	CLAMP - tube, plastic coated	7
112	13- 516	HHCS - 5/16" - 18 NC x 1"	7
113	92- 5	WASHER - med. sect. lock (5/16")	7
114	D 33551	SPACER - R17319 clamp (Bucket cyl. tubes only)	4
115	D 33552	SPACER - R17319 clamp (Cross-over tubes only)	3
116	D 31370	HOSE - to R.H. cylinder (1/2" I.D. x 1" O.D. x 30-7/16" long)	2
117	D 25137	TEE - adj., front port (5/8" JIC)	1
118	218- 5007	SEAL - "O" ring, D25137 tee	1
119	D 31365	TEE - adj. (5/8" JIC x 1/2" JIC)	1
120	D 31368	HOSE - cross-over, front (1/2" I.D. x 1" O.D. x 29-3/4" long)	1
121	218- 5007	SEAL - "O" ring, D31368	1
122	D 31366	HOSE - cross-over, rear (1/2" I.D. x 1" O.D. x 30" long)	1
123	31665	CLAMP - plate, metal (Use D33316)	1
124	D 33316	CLAMP - plate, plastic coated (R.H. side)	2
125	D 32039	CLAMP - plate, L.H. side (Upper)	1

(Con't on next page)



LOADER HYDRAULICS (BEFORE LOADER S/N 4110090)

REF.	PART NO.	DESCRIPTION	REQ'D
126 D	32040	CLAMP - plate, L.H. side (Lower)	1
127 13-	532	HHCS - 5/16" - 18 NC x 2"	2
128 92-	5	WASHER - med. sect. lock (5/16")	2
129 25-	105	NUT - hex. (5/16" - 18 NC)	2
130 D	31372	TUBE - bucket cyl.	2
131 D	25667	ELBOW - 90° male, rear ports (1/2" JIC x 5/8" JIC)	2
132 218-	5007	SEAL - "O" ring, D25667 elbow	1
133 D	31100	CYLINDER - dump, R.H. (Parts list p. 69)	1
134 D	31101	CYLINDER - dump, L.H. (Parts list p. 69)	1



S/N 4096200
THRU
4110811

FIG. 12B





FIG. A



SEE FIG. B


AFTER S/N 4110812

BN45065



LOADER HYDRAULICS (LOADER S/N 4110090 AND AFTER)

REF.	PART NO.	DESCRIPTION	REQ'D
1 D	33363	CONNECTOR - reservoir, 1" NPT x 1-1/4" O.D. tube	1
2 R	13911	HOSE - suction (1-1/4" I.D. x 1-3/4" O.D. x 4" long)	2
3	214- 258	CLAMP - R13911 hose	4
4 D	33822	TUBE - suction, used on ldr. sn. 4096200 thru 4110811	1
5 D	36752	TUBE - suction, used on ldr. sn. 4110812 and after	1
6 D	30511	ELBOW - 90° adj., 1-1/4" JIC x 1-1/4" O.D. tube (Used on ldr. sn. 4096200 thru 4110811)	1
7	218- 5011	SEAL - "O" ring, D30511 elbow	1
8 D	36747	CONNECTOR - hose, 1-1/4" JIC x 1-1/4" O.D. tube	1
9	218- 5011	SEAL - "O" ring, D36747 connector	1
10 D	31254	PUMP - hydraulic (Parts list p. 35)	1
11 13-	828	HHCS - 1/2" - 13 NC x 1-3/4"	2
12 29-	8	WASHER - med. sect. lock (1/2")	2
13 218-	5110	ELBOW - 90° adj., 1" JIC	1
14 218-	5010	SEAL - "O" ring, 218-5110	1
15 D	30563	TUBE - from pump, short	1
16 D	33579	TUBE - from pump, long	1
17 R	11405	CLAMP - D33579 tube	2
18 13-	58	HHCS - 5/16" - 18 NC x 1/2"	2
19 92-	5	WASHER - med. sect. lock (5/16")	2
20 D	24646	HOSE - to valve (3/4" I.D. x 1-1/4" O.D. x 25" long)	1
21 D	28890	CONNECTOR - male (3/4" JIC x 1" JIC)	1
22	218- 5010	SEAL - "O" ring, D28890 connector	1
23	REF	VALVE - loader control (See page 61)	1
24 D	31393	CONNECTOR - 3/4" JIC x 3/4" NPT	1
25 218-	5008	SEAL - "O" ring, D31393	1
26 221-	445	TEE - female, 3/4" NPT	1
27 221-	5	PLUG - pipe, sq. hd. (3/4" NPT)	1
28 R	11626	CONNECTOR - 45°, 3/4" NPT x 1" O.D. tube	1
29 D	36798	HOSE - to filter (1" I.D. x 1-1/2" O.D. x 10-5/8")	1
30 214-	256	CLAMP - D36798 hose	2
31 D	33588	CONNECTOR - 45° (1" O.D. tube x 3/4" NPT)	1
32 221-	411	ELBOW - 90° street (1/8" NPT)	1
33 D	29650	GAUGE - hyd. oil pressure	1
34 221-	65	BUSHING - reducing, 1" NPT to 3/4" NPT	1
35 D	32254	FILTER - hyd. oil, parts list p.	1
36 13-	816	HHCS - 1/2" - 13 NC x 1"	2
37 92-	8	WASHER - med. sect. lock (1/2")	2
38 195-	33	WASHER - plain (1/2")	2
39 217-	136	ELBOW - 90°, 1" NPT x 1" O.D. tube	1
40 D	32678	HOSE - return (1" I.D. x 1-1/2" O.D. x 29" long)	1
41 214-	256	CLAMP - D32678 hose	2
42 D	33590	ELBOW - 90°, 3/4" NPT x 1" O.D. tube	1
43 221-	14	PLUG - pipe, sq. hd. (1/2" NPT)	1
44 218-	5062	CONNECTOR - 5/8" JIC x 5/8" valve ports	3
45 218-	5007	SEAL - "O" ring, 218-5062 connector	1
46 D	36783	TUBE - from rear port	1
47 D	36781	TUBE - from front port	1
48 D	36851	TUBE - cross-over, front	1
49 D	36854	TUBE - cross-over, rear	1

(Con't on next page)



S/N 4096200
THRU
4110811




AFTER S/N 4110812

BN45045

LOADER HYDRAULICS (LOADER S/N 4110090 AND AFTER)

REF.	PART NO.	DESCRIPTION	REQ'D
50 R	17319	CLAMP - cross-over tubes	3
51 13-	520	HHCS - 5/16" - 18 NC x 1-1/4"	3
52 92-	5	WASHER - med. sect. lock (5/16")	3
53 D	33552	SPACER - clamp	3
54 D	30533	HOSE - to rear cyl. ports (1/2" I.D. x 1" O.D. x 26" long)	2
55 218-	5007	SEAL - "O" ring, D30533 hose	1
56 D	30541	HOSE - to front cyl. ports (1/2" I.D. x 1" O.D. x 27-1/2" long)	2
57 214-	264	CLAMP - tube	2
58 D	31460	TUBE - R.H. lift cyl.	1
59 D	31459	TUBE - L.H. lift cyl.	1
60 218-	5062	CONNECTOR - 5/8" JIC x 5/8" JIC	2
61 218-	5007	SEAL - "O" ring, 218-5062 connector	1
62 D	31463	CYLINDER - lift, R.H. (Parts list p. 67)	1
63 D	31464	CYLINDER - lift, L.H. (Parts list p. 67)	1
64 D	25137	TEE - adj. (5/8" JIC) Front port	1
65 218-	5007	SEAL - "O" ring, D25137 tee	1
66 D	37184	HOSE - to lower hydra-leveling cyl. port (1/2" I.D. x 1" O.D. x 24-1/2" long)	1
67 218-	5007	SEAL - "O" ring, D37184 hose	1
68 D	37185	HOSE - to upper hydra-leveling cyl. (1/2" I.D. x 1" O.D. x 16-1/2" long)	1
69 218-	5007	SEAL - "O" ring, D37185 hose	1
70 D	36882	CYLINDER - hydra-leveling (Parts list p. 71)	1
71 D	36785	HOSE - hydra-leveling cyl. to inside tube (1/2" I.D. x 1" O.D. x 23-1/2" long)	1
72 218-	5007	SEAL - "O" ring, D36785 hose	1
73 D	30543	HOSE - valve to outside tube (1/2" I.D. x 1" O.D. x 29" long)	1
74 D	33316	CLAMP - plate	2
75 13-	532	HHCS - 5/16" - 18 NC x 2"	1
76 D	33554	SPACER - clamp	1
77 95-	5	WASHER - std. wrot (5/16")	1
78 131-	4	NUT - hex, lock (5/16" - 18 NC)	1
79 D	31361	TUBE - on lift arm, outside	1
80 D	31359	TUBE - on lift arm, inside	1
81 R	17319	CLAMP - plastic coated	5
82 D	33551	SPACER - tube clamp	4
83 13-	516	HHCS - 5/16" - 18 NC x 1"	3
84 13-	520	HHCS - 5/16" - 18 NC x 1-1/4"	1
85 92-	5	WASHER - med. sect. lock (5/16")	4
86 D	31370	HOSE - to R.H. cylinder (1/2" I.D. x 1" O.D. x 30-7/16" long)	2
87 D	25137	TEE - adj., front port (5/8" JIC)	1
88 218-	5007	SEAL - "O" ring, D25137 tee	1
89 D	31365	TEE - adj. (5/8" JIC x 1/2" JIC)	1
90 D	31368	HOSE - cross-over, front (1/2" I.D. x 1" O.D. x 29-3/4" long)	1
91 218-	5007	SEAL - "O" ring, D31368 hose	1
92 D	31366	HOSE - crossover, rear (1/2" I.D. x 1" O.D. x 30" long)	1
93 D	33316	CLAMP - plate, plastic coated (R.H. side)	2
94 D	32039	CLAMP - plate, L.H. side (Upper)	1
95 D	32040	CLAMP - plate, L.H. side (Lower)	1
96 13-	532	HHCS - 5/16" - 18 NC x 2"	2

(Con't on next page)



S/N 4096200
THRU
4110811

FILE





FIG. 1A




SEE FIG. 1

AFTER S/N 4110812

BN45065


LOADER HYDRAULICS (LOADER S/N 4110090 AND AFTER)

REF.	PART NO.	DESCRIPTION	REQ'D
97 95-	5	WASHER - std. wrot (5/16")	2
98 131-	4	NUT - hex., lock (5/16" - 18 NC)	2
99 D	33554	SPACER - clamp plates	2
100 D	31372	TUBE - bucket cylinder	2
101 D	25667	ELBOW - 90° male, rear ports (1/2" JIC x 5/8" JIC)	2
102 218-	5007	SEAL - "O" ring, D25667 elbow	1
103 D	31100	CYLINDER - dump, R.H. (Parts list p. 69)	1
104 D	31101	CYLINDER - dump, L.H. (Parts list p. 69)	1



MULTI-PURPOSE BUCKET HYDRAULICS




REF.	PART NO.	DESCRIPTION	REQ'D
1 D	34409	BUCKET - multi-purpose, Drott (Parts list p. 11)	
2 D	34401	HOSE - at clam cyl. (3/8" I.D. x 7/8" O.D. x 60" long)	1
3	49855	CLAMP - D34401 hoses	2
4 13-	524	HHCS - 5/16" - 18 NC x 1-1/2"	2
5 95-	5	WASHER - std. wrot (5/16")	1
6 131-	4	NUT - hex., lock (5/16" - 18 NC)	1
7 218-	474	ELBOW - 90° (3/4" JIC)	2
8 D	34403	TUBE - valve to bucket, inside	1
9 D	34405	TUBE - valve to bucket, outside	1
10 R	17319	CLAMP - plate, tube	11
11 D	33316	CLAMP - plate, hose	2
12 D	33551	SPACER - tube clamp	6
13 D	33554	SPACER - hose clamp	1
14 13-	524	HHCS - 5/16" - 18 NC x 1-1/2"	1
15 13-	530	HHCS - 5/16" - 18 NC x 1-7/8"	3
16 13-	532	HHCS - 5/16" - 18 NC x 2"	1
17 13-	552	HHCS - 5/16" - 18 NC x 3-1/4"	1
18 95-	5	WASHER - std. wrot (5/16")	2
19 92-	5	WASHER - med. sect. lock (5/16")	3
20 131-	4	NUT - hex., lock (5/16" - 18 NC)	3
21 D	36734	HOSE - from valve to outside bucket cyl. tube on lift arm (1/2" I.D. x 42" long) Used before loader sn. 4110090	1
22 D	34399	HOSE - from valve to clam cyl. tubes (1/2" I.D. x 38-1/2" long)	2
23 D	34410	VALVE - loader control, three spool (Parts list page 47) Used before ldr. sn. 4110090	1
24 D	34412	BRACKET - D34410 loader valve	1
25	REF	VALVE - loader control, three spool (See page 53) Used on loader sn. 4110090 and after	1




530 CONSTRUCTION KING LOADER HYDRAULIC PUMP

35

REF.	PART NO.	DESCRIPTION	REQ'D
1	D 31254	PUMP - hydraulic (Cessna no. 20110-1 DBE "L" Series) 20 G.P.M. at 1900 R.P.M. and 2000 P.S.I. or 22 G.P.M. at 2100 R.P.M. and 2000 P.S.I. (For pump drive components see p. 67)	
2	D 31395	PLATE ASSEMBLY - front	1
3	D 31408	BODY AND DOWEL ASSEMBLY - center	1
4	D 31407	PLATE ASSEMBLY - rear	1
5	D 31405	DRIVESHAFT AND GEAR ASSEMBLY	1
6	D 31406	IDLER SHAFT AND GEAR ASSEMBLY	1
7	D 31396	KIT - major seal repair	1
7	D 31402	PLATE - thrust	1
8	D 31400	DIAPHRAGM	1
9	D 31398	GASKET - backup (Nylatron)	1
10	D 31399	GASKET - protector	1
11	D 31397	SEAL - diaphragm	1
12	D 31401	SEAL - shaft	1
13	D 31403	SPRING - ball retaining	2
14	D 31404	BALL - steel (13/32" dia.)	2
15	166- 54	SCREW - Ferry Cap (3/8" - 16 NC x 3-1/2")	4
16	166- 55	SCREW - Ferry Cap (3/8" - 16 NC x 3-1/4")	4




See Figure "A"



INCLUDES ITEMS 3 THRU 7

INCLUDES ITEMS 16 THRU 30



D31264 LOADER CONTROL VALVE

REF.	PART NO.	DESCRIPTION	REQ'D
D	31264	VALVE - hydraulic control (Use D32769) Parker series VDP-12	1
1	NSS	BODY - valve (Use D31264)	1
2	D 26243	SPOOL ASSEMBLY - three position (Color code - black, letter code - W) .73700" to .73709"	1
D	26244	SPOOL ASSEMBLY - three position (Color code - blue, letter code - X) .73710" to .73719"	1
D	26245	SPOOL ASSEMBLY - three position (Color code - yellow, letter code - Y) .73720" to .73729"	1
D	26246	SPOOL ASSEMBLY - three position (Color code - green, letter code - Z) .73730" to .73740"	1
3	R 17547	SEAL - "O" ring	1
4	A 14535	RETAINER - "O" ring	1
5	A 14533	SPACER - spring	2
6	A 14534	SPRING - spool return	1
7	A 13190	SNAP RING - retaining	1
8	A 14529	CAP - spool	1
9	R 17547	SEAL - "O" ring	2
10	A 14526	RETAINER - "O" ring	2
11	A 14527	SEAL - wiper	2
12	D 26283	RETAINER - handle brkt., short	1
13	D 32102	RETAINER - handle brkt., long	1
14	D 20771	SCREW AND LOCKWASHER	4
15	D 29847	SPOOL ASSEMBLY - four position (Color code - black, letter code - W) .73700" to .73709" (Use D32605) See page 41	1
D	11723	SPOOL ASSEMBLY - four position (Color code - blue, letter code - X) .73710" to .73719" (Use D32604) See page 41	1
D	29848	SPOOL ASSEMBLY - four position (Color code - yellow, letter code - Y) .73720" to .73729" (Use D32606) See page 41	1
D	29849	SPOOL ASSEMBLY - four position (Color code - green, letter code - Z) .73730" to .73740" (Use D32607) See page 41	1
NSS		SPOOL - float	1
16	A 16877	SEAL - "O" ring, outer	1
17	D 31433	RETAINER - "O" ring (Use 1-D33856 and 1-D33857)	1
18	D 33856	RETAINER - "O" ring, large	1
19	D 33857	RETAINER - "O" ring, small	1
20	R 17547	SEAL - "O" ring, inner	1
21	A 16879	SPACER - spool centering, rear	1
22	A 16882	SPRING - centering	1
23	A 16881	SPACER - spool centering, front	1
24	D 29840	BARREL - detent	1
25	D 32592	CAP AND SLEEVE ASSEMBLY	1
NSS		CAP - rear	1
NSS		SLEEVE - detent	1
26	211-5	BALL - steel (3/16" dia.)	6
27	A 16852	RETAINER - ball	1
28	D 31434	SPRING - detent	1
29	A 16884	CAP - front	1

(Con't on next page)







Fig. "A"



See Figure "A"

INCLUDES ITEMS
16 THRU 30INCLUDES ITEMS
3 THRU 7USE ON BACKHOE
MODELS ONLY

D31264 LOADER CONTROL VALVE

REF.	PART NO.	DESCRIPTION	REQ'D
30	178- 28	SCREW - set, socket head	1
D	26896	VALVE - secondary relief, rear port (1800 P.S.I. at 1.6 G.P.M.)	1
31	D 29853	SEAT - relief valve	1
32	D 37366	KIT - spring and plunger	1
33		RESERVED	
34	D 26899	SEAL - "O" ring, small	1
35	D 26897	FOLLOWER - spring	1
36	218- 5004	SEAL - "O" ring, cap	1
37	D 26900	CAP - relief valve	1
38	25- 154	NUT - hex., lock (1/4" - 28 NF)	1
39	176- 395	SCREW - set, headless (1/4" - 28 NF)	1
D	31458	VALVE - secondary relief, front port (2500 P.S.I. at 1.6 G.P.M.)	1
40	D 31986	SEAT - relief valve	1
41	D 37365	KIT - spring and plunger	1
42		RESERVED	
43	D 26899	SEAL - "O" ring, small	1
44	D 26897	FOLLOWER - spring	1
45	218- 5004	SEAL - "O" ring, cap	1
46	D 26900	CAP - relief valve	1
47	25- 154	NUT - hex., lock (1/4" - 28 NF)	1
48	176- 395	SCREW - set, headless (1/4" - 28 NF)	1
49	D 26259	SEAT - poppet	1
50	D 20756	NUT - acorn, relief valve	1
51	D 26270	WASHER - special	2
52	25- 155	NUT - jam	1
53	82- 514	SCREW - adjusting	1
54	D 26268	SPRING - pilot	1
55	D 26267	PLUNGER - pilot	1
56	D 26262	CAP - relief valve	1
57	218- 5006	SEAL - "O" ring, cap (outer)	1
58	D 26284	RING - backup	1
59	D 26265	SEAL - "O" ring, cap (inner)	1
60	D 26266	SEAT - relief valve	1
61	D 26261	SPRING - relief valve	1
62	A 16888	POPPET - relief valve	1
63	A 14532	CAP - check valve	2
64	A 14546	SEAL - "O" ring, cap	2
65	A 14520	SPRING - check valve	2
66	A 16886	POPPET - check valve	2
67	A 13192	PLUG - pipe, Allen head	1
68	D 26410	SEAL - "O" ring, plug	1
69	D 20774	PLUG - pipe, Allen head	1
70	D 26411	SEAL - "O" ring, plug	1
71	D 26467	PLUG - service	1
72	D 26410	SEAL - "O" ring, plug	1
73	221- 841	PLUG - pipe, 1/4" NPT	1
74	D 31314	LEVER - control, outside	1
75	D 25228	LEVER - control, inside	1
76	O 4413	PIN - handle	2
77	132- 25	PIN - cotter (3/32" x 5/8")	6
78	D 25483	LINK - handle (Plate)	4
79	141- 3	PIN - link	4
80	D 25783	PLUG - special, power beyond	1
81	218- 5008	SEAL - "O" ring, large	1
82	D 26435	SEAL - "O" ring, small	1

